


CA O	DESIGN		DRAWN BY			AEROSPACE (ESBURY, ONTARIO, CANAI		
6	CHECK	KED / /	APPROYED	DRAWING	G NO.			REV. A
Wossi F		4	#	DEO	9167		SHEET	1 OF 1
12	99.10.27			TITLE				SCALE
				вимі	PER			NTS
	Α		99.10.27	NEW	ISSUE			





DART ENGINEERING ORDER

FOR DART INTERNAL USE ONLY

AMEND THE FOLLOWING ASSEMBLY DRAWINGS:

D206-540 REV & H

D205-541 REV D

D350-607 REV E

REPLACE V1700 BUMPER (4) AND MS20600AD4W2 (4) RIVET WITH THE FOLLOWING:

D2931 BUMPER (4) 2

AN960JD8 WASHER (4) 2

MS20600AD4W3 RIVET (4) 2

DRILL Ø0.128 HOLE TO INSTALL

DO NOT INSTALL BUMPERS UMBERNEATH HANDLE. INSTALL (1) D2931 BUMPER AT THE FUD OF THE BASKET AND (1) D2931 BUMPER AT THE APT END OF THE BASKET

00.09.08 PF